

12cm


FOLD
VERTICALLY

One Year Unconditional Warranty

If for any reason, this ProMaster product fails within ONE YEAR of the date of purchase, return this product to your ProMaster dealer and it will be exchanged for you at no charge. ProMaster products are guaranteed for ONE FULL YEAR against defects in workmanship and materials. If, at any time after one year, your ProMaster product fails under normal use, we invite you to return it to ProMaster for evaluation.



[L Bracket]




Made in China

WWW.PROMASTER.COM | FAIRFIELD, CT 06825

16cm

FOLD
HORIZONTALLY



Thank you for purchasing this ProMaster L Bracket. Use it to quickly mount and dismount your camera from tripod heads which use the ProMaster dovetail / arca-swiss style quick release system. This product includes the correct hex wrench(s) to assemble and mount the L Bracket to your camera and to assemble / disassemble the 'L' from the baseplate (where applicable). First attach the L Bracket to the camera using the camera's 3/8" tripod connector. Figure 1 shows the mounting alignment of L bracket to camera. It also shows the proper mounting of the camera / L bracket combination to a tripod head horizontally. Figure 2 shows mounting the camera / L bracket combination to a head vertically. The L bracket can remain connected to your camera once attached.