



EDF Series Digital Electronic Flash Digital SLR Camera Compatibility

as of 1/1/2010

<u>Camera Model</u>	<u>7500</u> <u>EDF</u>	<u>7400</u> <u>EDF</u>	<u>7200</u> <u>EDF</u>	<u>7500</u> <u>DX</u>	<u>2500</u> <u>EDF</u>
<u>CANON</u>					
Canon Digital Rebel XS	7280	7308	7343	2037	2979
Canon Digital Rebel XSi	7280	7308	7343	2037	2979
Canon Digital Rebel XTi	7280	7308	7343	2037	2979
Canon Digital Rebel XT	7280	7308	7343	2037	2979
Canon Digital Rebel	7280	7308	7343	2037	2979
Canon Digital Rebel T1i	7280 ¹	7308 ¹	7343 ¹	N/A	2979
Canon EOS 50D	7280 ¹	7308 ¹	7343 ¹	N/A	2979
Canon EOS 40D	7280	7308	7343	2037	2979
Canon EOS 30D	7280	7308	7343	2037	2979
Canon EOS 20D	7280	7308	7343	2037	2979
Canon EOS 10D	7280	7308	7343	2037	2979
Canon EOS 7D	7280 ¹	7308 ¹	7343 ¹	N/A	2979
Canon EOS 5D Mark II	7280 ¹	7308 ¹	7343 ¹	N/A	2979
Canon EOS 5D	7280	7308	7343	2037	2979
Canon EOS 1D	7280	7308	7343	2037	2979
Canon EOS 1D Mark II/III	7280	7308	7343	2037	2979
Canon EOS 1DS/Mark III	7280	7308	7343	2037	2979
Canon EOS D30	7280	7308	7343	2037	2979
Canon EOS D60	7280	7308	7343	2037	2979

FUJI

Fuji S5	7287	7315	7350	6265	N/A
---------	------	------	------	------	-----

NIKON

Nikon D5000	7287	7315	7350	6265	2986
Nikon D3000	7287	7315	7350	6265	2986
Nikon D700	7287	7315	7350	6265	2986
Nikon D300	7287	7315	7350	6265	2986
Nikon D200	7287	7315	7350	6265	2986
Nikon D90	7287	7315	7350	6265	2986
Nikon D80	7287	7315	7350	6265	2986
Nikon D70	7287	7315	7350	6265	2986
Nikon D70S	7287	7315	7350	6265	2986
Nikon D60	7287	7315	7350	6265	2986
Nikon D50	7287	7315	7350	6265	2986
Nikon D40	7287	7315	7350	N/A	2986
Nikon D40X	7287	7315	7350	N/A	2986
Nikon D3	7287	7315	7350	6265	2986

OLYMPUS

Olympus Evolt E620	1110	1117	7490	N/A	4533
Olympus Evolt E520	1110	1117	7490	N/A	4533
Olympus Evolt E510	1110	1117	7490	N/A	4533
Olympus Evolt E500	1110	1117	7490	N/A	4533
Olympus Evolt E420	1110	1117	7490	N/A	4533
Olympus Evolt E410	1110	1117	7490	N/A	4533
Olympus Evolt E330	1110	1117	7490	N/A	4533
Olympus Evolt E300	1110	1117	7490	N/A	4533
Olympus E3	1110	1117	7490	N/A	4533
Olympus E1	1110	1117	7490	N/A	4533
Olympus EP-1	1110	1117	7490	N/A	4533
Olympus E10	1110	1117	7490	N/A	4533

1 - With version 2 software update

<u>Camera Model</u>	<u>7500</u> <u>EDF</u>	<u>7400</u> <u>EDF</u>	<u>7200</u> <u>EDF</u>	<u>7500</u> <u>DX</u>	<u>2500</u> <u>EDF</u>
<u>PANASONIC</u>					
G1	N/A	N/A	N/A	N/A	4533
GH1	N/A	N/A	N/A	N/A	4533
GF1	N/A	N/A	N/A	N/A	4533
<u>PENTAX</u>					
Pentax K2000D	7273	7301	7336	N/A	N/A
Pentax K200D	7273	7301	7336	N/A	N/A
Pentax K100D Super	7273	7301	7336	N/A	N/A
Pentax K100D	7273	7301	7336	6335	N/A
Pentax K110D	7273	7301	7336	6335	N/A
Pentax K20D	7273	7301	7336	N/A	N/A
Pentax K10D	7273	7301	7336	N/A	N/A
Pentax *ist D	N/A	N/A	N/A	N/A	N/A
Pentax *ist DL	7273	7301	7336	6335	N/A
Pentax *ist DS	7273	7301	7336	6335	N/A
Pentax K7D	N/A	N/A	N/A	N/A	N/A

SAMSUNG

Samsung GX-10	7273	7301	7336	6335	N/A
Samsung GX-1L	7273	7301	7336	6335	N/A
Samsung GX-1S	7273	7301	7336	6335	N/A

SONY

Sony Alpha A900	7294	7322	7329	N/A	N/A
Sony Alpha A850	7294	7322	7329	N/A	N/A
Sony Alpha A700	7294	7322	7329	N/A	N/A
Sony Alpha A550	7294	7322	7329	N/A	N/A
Sony Alpha A500	7294	7322	7329	N/A	N/A
Sony Alpha A380	7294	7322	7329	N/A	N/A
Sony Alpha A350	7294	7322	7329	N/A	N/A
Sony Alpha A200	7294	7322	7329	N/A	N/A
Sony Alpha A330	7294	7322	7329	N/A	N/A
Sony Alpha A200	7294	7322	7329	N/A	N/A
Sony Alpha A230	7294	7322	7329	N/A	N/A
Sony Alpha A100	7294	7322	7329	N/A	N/A



5000 Series Modular Electronic Flash Digital SLR Camera Compatibility

as of 1/1/2010

<u>Camera Model</u>	<u>5050DXR</u>	<u>5000DX</u>
<u>CANON</u>		
Canon Digital Rebel XS	7133	2044
Canon Digital Rebel XSi	7133	2044
Canon Digital Rebel XTi	7133	2044
Canon Digital Rebel XT	7133	2044
Canon Digital Rebel	7133	2044
Canon EOS T1i	7133 ¹	N/A
Canon EOS 50D	7133 ¹	N/A
Canon EOS 40D	7133	2044
Canon EOS 30D	7133	2044
Canon EOS 20D	7133	2044
Canon EOS 10D	7133	2044
Canon EOS 7D	7133 ¹	N/A
Canon EOS 5D Mark II	7133 ¹	N/A
Canon EOS 5D	7133	2044
Canon EOS 1D	7133	2044
Canon EOS 1D Mark II/III	7133	2044
Canon EOS 1DS/Mark III	7133	2044
Canon EOS D30	7133	2044
Canon EOS D60	7133	2044

<u>FUJI</u>		
Fuji S5	7147	6258

<u>NIKON</u>		
Nikon D5000	7147	6258
Nikon D3000	7147	6258
Nikon D700	7147	6258
Nikon D300	7147	6258
Nikon D200	7147	6258
Nikon D90	7147	6258
Nikon D80	7147	6258
Nikon D60	7147	6258
Nikon D70	7147	6258
Nikon D70S	7147	6258
Nikon D50	7147	6258
Nikon D40	7147	6790
Nikon D40X	7147	6790

<u>OLYMPUS</u>		
Olympus Evolt E620	7154	5425
Olympus Evolt E520	7154	5425
Olympus Evolt E510	7154	5425
Olympus Evolt E500	7154	5425
Olympus Evolt E420	7154	5425
Olympus Evolt E410	7154	5425
Olympus Evolt E330	7154	5425
Olympus Evolt E300	7154	5425
Olympus E3	7154	5425
Olympus E1	7154	5425
Olympus E10	7154	5425
Olympus EP-1	7154	5425

<u>Camera Model</u>	<u>5050DXR</u>	<u>5000DX</u>
<u>PENTAX</u>		
Pentax K2000D	7161	N/A
Pentax K200D	7161	N/A
Pentax K100D Super	7161	N/A
Pentax K100D	7161	5432
Pentax K110D	7161	5432
Pentax K20D	7161	N/A
Pentax K10D	7161	N/A
Pentax *ist D	N/A	2708
Pentax *ist DL	7161	5432
Pentax *ist DS	7161	5432
Pentax K7D	N/A	N/A

<u>SAMSUNG</u>		
Samsung GX-10	7161	N/A
Samsung GX-1L	7161	5432
Samsung GX-1S	7161	5432

<u>SONY</u>		
Sony Alpha A900	7140	N/A
Sony Alpha A850	7140	N/A
Sony Alpha A700	7140	N/A
Sony Alpha A550	7140	N/A
Sony Alpha A500	7140	N/A
Sony Alpha A380	7140	N/A
Sony Alpha A350	7140	N/A
Sony Alpha A200	7140	N/A
Sony Alpha A330	7140	N/A
Sony Alpha A200	7140	N/A
Sony Alpha A230	7140	N/A
Sony Alpha A100	7140	N/A