





XtraPower UNIVERSAL Digital Camera Battery Charger

For Lithium Ion Digital Camera Batteries

The PROMASTER Universal Digital Camera Li-Ion Charger is designed for use with most 3.6V-7.6V Lithium Ion digital camera batteries. When used correctly, the charger will automatically detect the polarity and voltage of the battery and select the correct charge setting.

IMPORTANT: Please read and follow all instructions before using this product.



OPERATING INSTRUCTIONS:

- Make sure that the DC cable is NOT connected.
- Lift the cover and unlock the contact blocks on the charger by lifting the two levers. The two contact blocks can then be moved along the charger slot.
- Align the two contacts with the positive and negative terminals indicated on the battery. It is not necessary to connect the charger contacts to a third battery terminal (if one exists.) The charger will automatically detect the polarity and the charging voltage of the battery.
- Insert the battery into the charger. The battery may be placed flat or upright, depending on the position of the terminals.
- Move the slider forward by compressing the buttons on both sides of the slider. Position the slider so that the battery is firmly held in place. Make certain that the battery terminals and the charger contacts are firmly connected.
- Lock the contact blocks on the charger by pushing down the two levers.
- Plug the AC/DC adapter jack into the input socket on the side of the charger and then plug the adapter into a suitable AC main power outlet.
- When working properly, the charger indicator bar will appear as follows:

| | |
|------------------------------|-------------------------------|
| Red (flashing): | Power is connected |
| Red (solid): | Battery is attached |
| Green (solid): | Battery is 80% charged |
| Green (flashing): | Charging is complete |
| Red/Green (flashing): | Battery failure |

Battery Failure

If the charger indicates battery failure or does not seem to be working, unplug the charger and wait 30 seconds, then plug the charger in again. If the charger still does not appear to be working, remove the battery.

Battery Care

To prolong battery life, charge Lithium Ion batteries to 80% capacity (NOT to full capacity). The charger indicator will be solid Green when the battery has reached 80% capacity. As Lithium Ion batteries do not have memory effect, they may be charged at any level of discharge and may be taken out of the charger at any time.

Limited Warranty

This product carries a full one-year warranty from the date of purchase against defects in materials and workmanship. This warranty does not cover damage resulting from accidents, misuse, unauthorized repair or alternations to the product or failure to follow operating instructions. If the product should become defective within the warranty period and under the above-mentioned conditions, please return it to the PROMASTER dealer you originally purchased it from, with proof of purchase for repair or replacement free of charge.

Charging Time

| Battery Capacity | 80% full | 100% full |
|------------------|--------------------|--------------------|
| 800 mAh | 1 hour 25 minutes | 2 hours 15 minutes |
| 1600 mAh | 2 hours 55 minutes | 4 hours 50 minutes |