



PROMASTER®

MicroClean

**Ultra Fine Microfiber
Cleaning Cloth**

*PROMASTER is a supplier of premium quality lenses,
digital camera memory, batteries and accessories, filters,
digital and conventional electronic flashes,
camera cases and tripods.*



Code 5378

The PROMASTER® MicroClean cloth is a special high-density treated fabric that absorbs oils and easily removes fingerprints, dust and other particles from your delicate lens and LCD surfaces, leaving them sparkling clean and clear. The MicroClean cloth is safe for use on all coated optical surfaces as well as glass, plastic, polycarbonate and LCD surfaces.

TO CLEAN DRY LENSES: Remove heavy dust and then lightly wipe each surface with your PROMASTER MicroClean cloth.

TO CLEAN WITH OPTICAL CLEANING FLUID: Apply cleaning fluid per the manufacturer's instructions and wipe dry with your PROMASTER MicroClean Cloth.

TO KEEP CLOTH CLEAN: Hand or machine wash in warm sudsy water. Machine dry on low setting.