

PROMASTER® Emergency!

Portable Charger, Power Supply and Flashlight

PLEASE READ THIS INFORMATION THOROUGHLY BEFORE USING THIS PRODUCT. IT CONTAINS IMPORTANT OPERATING INSTRUCTIONS FOR YOUR UNIT.

Owner's Manual

Thank you for purchasing the PROMASTER® Emergency!. The PROMASTER® Emergency! offers the convenience of an external battery, charger, and LED flashlight built into a portable, compact, easy to use footprint.

The dual USB output it is suitable for charging and powering various USB devices and the super bright 4 LED flashlight will provide up to 15 hours of illumination.

Included in the package:


- PROMASTER® Emergency!
- USB charging cable
- Owner's manual.

Charging your PROMASTER® Emergency!

Prior to initial use be sure to fully charge your PROMASTER® Emergency!
The PROMASTER® Emergency! has two charging options:

From USB


Plug the Micro USB end of the supplied cable into the PROMASTER® Emergency!, plug the other end into any computer USB port or a wall plug style adapter with a USB. The red capacity meter light will indicate that the PROMASTER® Emergency! is charging.



OR

From Automobile DC outlet


To use the built-in DC car charger, slide back the red transparent cover and swivel the DC power plug outward, up to 180 degrees and then plug into your car's 12V DC outlet. The red capacity indicator will indicate that the PROMASTER® Emergency! is charging.



Charging Status

During charging, the LED battery meter shows the current charging status of the PROMASTER® Emergency!. When the unit is plugged in to either a USB port or the car's cigarette lighter charging status is indicated as follows:


One LED indicates the unit is about 25% charged.
Two LEDs indicate the unit is about 50% charged.
Three LEDs indicate the unit is about 75% charged.
Four LEDs indicate a full 100% charge.



Using your PROMASTER® Emergency!

Power Switch

To charge or power your device from the PROMASTER® Emergency!'s internal power source, connect your device to one of the two USB outputs and slide the power switch to the "ON" position. The PROMASTER® Emergency! will begin to charge or power your connected device. The blue LED will illuminate showing the PROMASTER® Emergency! is on. To turn the PROMASTER® Emergency! off, slide the power button to the "OFF" position.



Dual USB Outlets

The PROMASTER® Emergency!'s dual USB outputs offer the convenience of charging or powering two devices at the same time.

Flashlight

To use the built in LED flashlight, push the flashlight button to turn the flashlight on or off. The flashlight will operate up to fifteen hours of use on a single charge.

Checking the Remaining Capacity of the PROMASTER® Emergency!

The remaining capacity of the PROMASTER® Emergency!'s internal battery is indicated by the LED lights on the battery meter. To check the remaining capacity, press the button below the battery meter. The remaining capacity is as follows:

One LED indicates a charge is needed immediately.
Two LEDs indicate there is about 50% of its power remaining.
Three LEDs indicate there is about 80% of its power remaining.
Four LEDs indicate a full 100% charge.

Specifications

Cell type: Lithium-Polymer Battery
Capacity: 1000mAh
Charging time: Approximately 3 hours
Input from USB: DC 5V, 500mA
Input from DC power plug: DC 12-24 V
Output using Internal Battery: DC 5V±5%, 500mA
Output using 12V DC power: DC 5V±5%, 1A
Dimensions: L85 x W61 x H30mm
Weight: 95g
Flashlight Illumination Time: Approx. 15 hours.

Includes built in over current protection programmed into the IC

PROMASTER® One Year LIMITED WARRANTY:

- 1) To claim warranty service, return your product to your Authorized PROMASTER® Dealer along with a copy of the original sales receipt from an Authorized PROMASTER® dealer bearing the purchaser's name, date of purchase and description of the item being submitted for warranty service. If it is not practical to return it to your Authorized PROMASTER® dealer, your product may be returned PREPAID to the PROMASTER® WARRANTY CENTER listed below.
- 2) If, in the sole opinion of PROMASTER®, this product has become non-functional due to a defect in the workmanship or materials at the original point of manufacturing, PROMASTER® will repair or replace (at PROMASTER®'s option) this product without charge. In the event of replacement, PROMASTER® reserves the right to substitute a like reconditioned product with similar characteristics. If not prohibited by local law, a handling fee may apply.
- 3) This warranty will be considered NULL and VOID in the following cases:
 - a) Damage to the product due to mishandling, alteration, accident, impact, sand and/or liquid or moisture damage, tampering, battery or chemical corrosion, failure to follow operating, maintenance, or environmental instructions prescribed by the instruction manual, shipping damage, excessive use; or
 - b) Damage caused during service performed by anyone other than the authorized PROMASTER® service center; or
 - c) If the product has had its serial number or other identifying data altered or removed; or
 - d) Damage, defect, or unsatisfactory performance caused by the use of accessories not manufactured or distributed by PROMASTER®; or
 - e) The product was not purchased from an Authorized PROMASTER® dealer.
- 4) In no event will PROMASTER® be liable for any loss or damage, including any damage to connected devices, other inconvenience, lost profits, lost savings, or other incidental or consequential damages arising out of the use or inability to use this product.

PROMASTER® WARRANTY CENTER
2950 Turnpike Drive, Section 6 – 9
Hathboro, PA 19040

Be sure to include a copy of your sales receipt which clearly identifies your product, your name, and the date and place of purchase. In addition be sure to include a brief description of the problem you are experiencing with the product.

Code B250
Made in China

Lithium-Polymer batteries should be recycled or disposed of properly.

www.promaster.com
Fairfield, CT 06825

