

[pro]master®

[SD/MS Multi Card Reader]

*Reads and writes to all Secure Digital
& Memory Stick formats*


Thank you for purchasing the ProMaster® SD/MS Multi Memory Card Reader/Writer. The ProMaster® SD/MS Multi Memory Card Reader/Writer lets you access your pictures or other files from a memory card without the need to directly connect a camera or other media device to your computer.

Follow the simple instructions in this user manual and enjoy the benefits of these convenient features:

- Easily access media and manage content almost anywhere
- Includes slot-to-slot read/write/copy and USB mass-storage capabilities
- Secure Digital (SD), Secure Digital High Capacity (SDHC), Secure Digital Extended Capacity (SDXC), Micro Secure Digital (Micro SD), Mini Secure Digital (Mini SD), Micro Secure Digital (Micro SD)/T-Flash, MultiMediaCard (MMC), RS MultiMediaCard (RS-MMC), MultiMedia Micro (MMC Micro), MultiMedia Plus 4.0 (MMC Plus 4.0), MultiMedia Mobile (MMC Mobile), Memory Stick (MS), Memory Stick PRO (MS PRO), Memory Stick Duo (MS Duo), Memory Stick PRO Duo (MS PRO Duo), Memory Stick PRO HG DUO, Micro MS (M2), Memory Stick Micro*
*Some cards may require adapter supplied by memory card manufacturer.
- Supports automatic card detection and USB 2.0 high speed data transfer
- Eliminates need for direct connection of media device to save battery power
- Windows, Mac, and Linux compatible — hot swappable, Plug and Play

INSTALLATION

- Connect the ProMaster® SD/MS Multi Memory Card Reader/Writer to any open USB port on your computer.
- Double-click on "My Computer" to confirm that the A drive letter labeled Removable Disk appears.
- Check that the blue power LED light on the reader comes on to confirm a proper connection.
- Insert your memory card in the appropriate reader slot to use the card reader function.
- Double-click on the corresponding drive letter to read or write desired files to or from your computer or storage card.



SLOT IDENTIFICATION

Please refer to the diagram above:

- Slot 1 - Memory Stick/Memory Stick Duo
- Slot 2 - Micro SD/T-Flash
- Slot 3 - Secure Digital/MMC
- Slot 4 - Micro MS (M2)/Memory Stick Micro

OPERATIONS GUIDE

OVERVIEW

The read and write commands for memory cards are the same as those used for moving data to and from any other computer storage device, such as a USB drive or floppy disk. You simply plug the ProMaster® SD/MS Multi Memory Card Reader/Writer into any USB port of your PC or Mac and begin transferring information stored on flash media cards to your computer and back.

OPERATING TIPS

Copying Files Between Memory Cards

In addition to moving data between your Reader/Writer and your computer, you may move data between card types. Assuming an SD card was inserted, you could copy this data to a Memory Stick also inserted in the Reader/Writer. Note: Data from an SD card CANNOT be copied directly to an MMC or a Mini SD card. The same situation applies to Memory Stick. When MS card is inserted, data from the MS card CANNOT be copied directly to an MS Duo card or MS Micro (M2). All other potential card configuration scenarios allow for direct data transfer from card to card.

Inserting Secure Digital Card (SD), MultiMediaCard (MMC) and Memory Stick (MS)

Insert MMC and MS cards with metal contact strips facing down and notched corners facing into the appropriate labeled slot on the ProMaster® SD/MS Multi Memory Card Reader/Writer. For SD, insert the cards with metal contact strips facing up.

Be sure to push the memory card all the way into the ProMaster® Reader/Writer. To remove cards, pull out the cards carefully.

SPECIFICATIONS

- Type: Hi-Speed USB 2.0, USB 1.1, CE, FCC, WEEE
- Connection: USB type A male
- Performance: Transfer rate up to 480Mbps for USB 2.0
- Operating Environment: 0°C to 40°C and 10% to 90% Relative Humidity

SYSTEM REQUIREMENTS

- USB port
- Compatible with
 - Windows XP, Vista, Windows 7, Windows 8
 - Mac OS 9.2 or 10.1.2.3 or higher
 - Most Linux Operating Systems

KEEP IN TOUCH

For more information, tutorials, industry news and tips & tricks, make sure to visit us at promaster.com, follow our feeds on Twitter @promasterphoto, and subscribe to our YouTube Channel username ProMasterChannel.

ONE YEAR UNCONDITIONAL GUARANTEE

If for any reason, this ProMaster product fails within ONE YEAR of the date of purchase, return this product to your ProMaster® dealer and it will be exchanged for you at no charge. ProMaster products are guaranteed for ONE FULL YEAR against defects in workmanship and materials. If at any time after one year, your ProMaster® product fails under normal use, we invite you to return it to ProMaster® for evaluation.

Code 5230

Made in China

www.promaster.com | Fairfield, CT 06825