



[pro]master®

HOW TO USE THE O-RING

1.



2.



1. Flip the deluxe soft shutter release over.
2. Push the o-ring completely over its threads.
3. Attach the deluxe soft shutter release to your camera.

The o-ring is useful with many FUJIFILM X series cameras. It helps reduce the chance of the deluxe soft shutter release from accidentally becoming loose and falling off. You can try the o-ring with any type of camera having a traditional, threaded shutter release button to see if it is a beneficial addition. Only use an o-ring if it provides a more secure fit with the particular model of camera. In some cases you may not be able to thread the deluxe soft shutter release far enough into the shutter button's threaded release port with an o-ring installed. In this case do not use an o-ring. Only use 1 o-ring at a time. 2 are included only so you will have a spare.